

ONYXWorks™ Protected Premises and Proprietary Supervising Station

This document must be printed, then framed and posted where it is visible from the ONYXWorks™ Workstation.

Name:

NOTIFIER® by Honeywell.

Model Numbers:

Part Number	Description
ONYXWORKS	Protected Premises or Proprietary Supervising Station Workstation.
ONYXWORKS-NF	Protected Premises or Proprietary Supervising Station Workstation. - Includes NCS-NCW network card and NFN Gateway Software.
ONYXWORKS-NW	Protected Premises or Proprietary Supervising Station Workstation. - Includes NCS-NCF network card and NFN Gateway Software.
ONYXWORKS-EW	Proprietary Supervising Station Workstation. - Includes PCLTA-20 Echelon network card and Echelon Gateway Software.

Electrical Ratings:

- 7 A @ 115V 60Hz (PC).
- 4 A @ 230V 50Hz (PC).
- 1.8A @ 100V-240VAC (MON-17LCD).
- All terminals are power limited.

Use:

- Commercial protected premises control unit.
- Commercial supervising station unit.
- Suitable for proprietary "A" burglar alarm service.

Type of Fire Alarm System Supported by the Product:

When installed in accordance with the supplied manuals, this product complies with the following NFPA 72 standards for fire protective signaling systems:

- Proprietary Protected Premise Unit.
- Proprietary Receiving Unit.
- Central Station Receiving Unit.

NFPA Standards Reference:

Complies with NFPA 72 and NFPA 70.

Alarm Signal Types:

- Automatic Fire Alarm.
- Manual Fire Alarm.
- Waterflow Alarm.
- Sprinkler Supervisory Service.
- Proprietary Grade "A" Burglar Alarm.

Type of Signaling:

Other Transmission Technologies as outlined in NFPA 72 (2002) Section 8.5.4.

Installation References:

This system must be installed, maintained, and operated in accordance with the following Revision A documents:

- 52342 ONYXWorks™ Workstation Manual
- 52345 ONYXWorks™ System Utilities Manual
- 52326 ONYXWorks™ NetLogic Manual

Improper installation, maintenance and lack of routine testing could result in system malfunction. Installation limits under jurisdiction of local authority.

Operating System Software:

Software version information can be displayed by selecting the Help>About menu selection on the ONYXWorks™ Workstation screen.

Intended Use:

Intended for dry indoor locations and environments.