

ONYXWorks[®] Protected Premises and Proprietary Supervising Station

This document must be printed, then framed and posted where it is visible from the ONYXWorks[®] Workstation.

Name: NOTIFIER[®] by Honeywell.

Model Numbers:

Part Number	Description
ONYXWORKS	Protected Premises or Proprietary Supervising Station Workstation.
ONYXWORKS-NW	Protected Premises or Proprietary Supervising Station Workstation. – Includes NFN-GW-PC-W network card and NFN Gateway Software.
ONYXWORKS-NF	Protected Premises or Proprietary Supervising Station Workstation. – Includes NFN-GW-PC-F network card and NFN Gateway Software.
ONYXWORKS-EW	Proprietary Supervising Station Workstation. – Includes ECH-GW-PC-W Echelon network card and Echelon Gateway Software.
ONYXWORKS-HNW	Protected Premises or Proprietary Supervising Station Workstation. – Includes HS-NFN-GW-PC-W network card and NFN Gateway Software.
ONYXWORKS-HNSF	Protected Premises or Proprietary Supervising Station Workstation. – Includes HS-NFN-GW-PC-SF network card and NFN Gateway Software.
ONYXWORKS-HNMF	Protected Premises or Proprietary Supervising Station Workstation. – Includes HS-NFN-GW-PC-MF network card and NFN Gateway Software.

Electrical Ratings:

- 7 A @ 115V 60Hz (PC).
- 4 A @ 230V 50Hz (PC).
- 1.8A @ 100V-240VAC (MON-17LCD).
- All terminals are power limited.

Use:

- Commercial protected premises control unit.
- Commercial supervising station unit.
- Suitable for proprietary "A" burglar alarm service.

Type of Fire Alarm System Supported by the Product:

When installed in accordance with the supplied manuals, this product complies with the following NFPA 72 standards for fire protective signaling systems:

- Proprietary Protected Premise Unit.
- Proprietary Receiving Unit.
- Central Station Receiving Unit.

NFPA Standards Reference: Complies with NFPA 72 and NFPA 70.

Alarm Signal Types:

- Automatic Fire Alarm.
- Manual Fire Alarm.
- Waterflow Alarm.
- Sprinkler Supervisory Service.

- Proprietary Burglar Alarm.

Type of Signaling: Other Transmission Technologies as outlined in NFPA 72 (2002) Section 8.5.4.

Installation References: This system must be installed, maintained, and operated in accordance with the following documents:

- ONYXWorks[®] Echelon Gateway (P/N 52305)
- ONYXWorks[®] NFN Embedded Gateway (P/N 52306)
- ONYXWorks[®] NFN Embedded Gateway-3 (P/N 53369)
- ONYXWorks[®] NFN PC Gateway (P/N 52307)
- ONYXWorks[®] NFN PC Gateway with HS-NCS (P/N 53370)
- ONYXWorks[®] Receivers Gateway (P/N 52308)
- ONYXWorks[®] NetLogic (P/N 52326)
- ONYXWorks[®] Workstation Manual (P/N 52342)

Improper installation, maintenance and lack of routine testing could result in system malfunction. Installation limits under jurisdiction of local authority.

Operating System Software: Software version information can be displayed by selecting the Help>About menu selection on the ONYXWorks[®] Workstation screen.

Intended Use: Intended for dry indoor locations and environments.



WARNING:
DISCONNECT POWER BEFORE OPENING.

ADVERTISSEMENT:
COUPER LE COURANT AVANT D'OUVRIER.